

Installation, Operation, & Maintenance Manual

IOM8402 Rev. A 03/22

FPE SERIES Vertical Packaged Electric Heat / Electric Cooling Unit









COPYRIGHT

First Co. works to continuously improve its products and as a result, it reserves the right to change design and specifications without notice.

The warranty may be void unless the Startup & Performance Checklist is completed and returned to the warrantor. If the FIRST-PAK air conditioner is not installed properly, the warranty will be void, as the manufacturer cannot be held accountable for problems that stem from improper installation.

©2022 First Co., 8273 Moberly Lane, Dallas, TX 75227

WARNING TO INSTALLER, SERVICE PERSONNEL AND OWNER

Altering the product or replacing parts with non-authorized factory parts voids all warranty or implied warranty and may result in adverse operational performance and/or a possible hazardous safety condition to service personnel and occupants. Company employees and/or contractors are not authorized to waive this warning.

SAFETY CONSIDERATIONS	4-5
MODEL NOMENCLATURE	6
GENERAL INFORMATION	7
INTRODUCTION	7
STORAGE	8
SHIPPING & PACKAGE LIST	8
UNIT INSPECTION CHECKLIST	9
UNIT DIMENSIONAL DATA	10
UNIT PHYSICAL DATA	11
ELECTRICAL DATA	12
PERFORMANCE	12
INSTALLATION	13-20
REQUIREMENTS	13
INSTALLATION PRECAUTIONS	13
UNIT LOCATION	13
UNIT CLEARANCE REQUIREMENTS	14
WALL SLEEVE INSTALLATION	15
UNIT SUPPORT	16
PACKAGED UNIT INSTALLATION	17-18
DUCTWORK	19
CONDENSATE DRAINAGE	19
AIR FILTER	20
ELECTRICAL	20-22
CONTROLS	23-26
COOLING OPERATIONS	23
BLOWRE CONTROL	24-26
HEATING OPERATIONS	27
LOCATION OF MAJOR COMPONENTS	28
REPLACEMENT PARTS	29
WIRING DIAGRAMS	30-39
CIRCUIT SCHEMATIC	40
STARTUP INSTRUCTIONS	40-41
TROUBLESHOOTING	42-43
HEATING	42
COOLING	43
MAINTENANCE & SERVICE	43-47
HEATING	43-45
COOLING	45-47
STARTUP & PERFORMANCE CHECKLIST	48-49
INDEXES	50-51

SAFETY CONSIDERATIONS

1. READ THE ENTIRE MANUAL BEFORE STARTING THE INSTALLATION.

- 2. These instructions are intended as a general guide and do not supersede national, state, or local codes in any way.
- 3. Altering the product, improper installation, or the use of unauthorized factory parts voids all warranty or implied warranty and may result in adverse operation and/or performance <u>or</u> may result in hazardous conditions to service personnel and occupants. Company employees or contractors are not authorized to waive this warning.
- 4. This product should only be installed and serviced by a qualified, licensed, and factory authorized installer or service agency.
- 5. All "kits" and "accessories" used must be factory authorized when modifying this product. Refer and follow instructions packaged with the kits or accessories when installing.

RECOGNIZE THE FOLLOWING SAFETY NOTATIONS THROUGHOUT THIS MANUAL AND POSTED ON THE EQUIPMENT:



Verify proper operation after servicing.

SAFETY CONSIDERATIONS CONTINUED



WARNING

Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury or loss of life. Refer to the user's information manual provided with this unit. Installation and materials, service must be performed by a qualified installer, service agency.



WARNING

Installation and service must be performed by a licensed professional installer (or equivalent), service agency. Attempting to install or repair this unit without such background may result in product damage, personal injury or death.



WARNING

These instructions are intended as an aid to qualified, licensed service personnel for proper installation, adjustment and operation of this unit. Read these instructions thoroughly before attempting installation or operation. Failure to follow these instructions may result in improper installation, adjustment, service or maintenance possibly resulting in fire, electrical shock, property damage, personal injury or death.











ł

Disconnect all power before servicing. Failure to do so may result in property damage, personal injury, or death.

CAUTION

Use care when handling compressors. Some temperatures could be hot!

CAUTION



Compressors should not be used to evacuate the air conditioning system. Vacuums this low can cause internal electrical arcing resulting in a damaged or failed compressor.





The unit must be permanently grounded. Failure to do so can cause electrical shock resulting in severe personal injury or death.





"USE COPPER SUPPLY WIRES ONLY!"

MODEL NOMENCLATURE

	FP 1 2	<u>Е</u> з	05 4 5	<mark>E1</mark> 6 7	<u>C</u> 8	<u>18</u> 9 10	A 11	<u>2</u> ^{<u>000</u>} <u>F</u> 13 14 15 16	
SERIES									BRAND
НЕАТ ТҮРЕ									OPTIONS
HEAT CAPACITY (KW)									VOLTAGE
HEAT CONFIGURATION									REVISION
UNIT TYPE									COOLING CAPACITY / SIZE



MODEL NUMBER DESCRIPTION

DIGITS 1-2 – SERIES	DIGITS 9-10 – CAPACITY	
FP – FIRST-PAK	09 – 9,000 Btu/Hr	
	12–12,000 Btu/Hr	
DIGIT 2 – HEAT TYPE	18–18,000 Btu/Hr	
E – Electrical Heat	24–24,000 Btu/Hr	
	30 – 30,000 Btu/Hr	
DIGITS 4-5 – HEAT CAPACITY (KW OR BTU/HR)		
00 – No Heat	DIGIT 11 – REVISION LEVEL	
05 – 5kw	A -	
07 – 7kw		
10 – 10kw	DIGIT 12 – VOLTAGE	
15 – 15kw	2 – 208/230v 1Ph	
	DIGITS 13-15 - OPTIONS	
DIGITS 6-7 – HEAT CONFIGURATION	000 - NONE	
00 – No Heat		
E1 – Single Stage Elec Heat	DIGIT 16 – BRAND	
	F – First Co.	

DIGIT 8 – UNIT TYPE

C – Cooling Only H – Heat Pump

GENERAL INFORMATION

CAUTION

DO NOT use these units as a source of heating or cooling during the construction process. Mechanical components and filters can become clogged with dirt and debris, which can cause damage to the system.

The manufacture does not warrant equipment subjected to abuse.

WARNING ELECTRIC SHOCK HAZARD

Before servicing equipment, ALWAYS turn off all power to the unit. There may be more than one disconnect switch. Electrical shock can cause injury or death.

Clear surrounding area of all tools, equipment, and debris before operating this unit.

These instructions are provided for the installation of the FIRST-PAK air conditioner specifically. For any other related equipment, refer to the appropriate manufacturer's instructions.



ł

WARNING

This air conditioner is certified for through-the-wall indoor installation only. This air conditioner is **NOT** approved for mobile homes, recreational vehicles or outdoor applications. Such use could result in property damage, personal injury, or death.

This air conditioner must never be operated under any circumstances without an air filter in place.

0

NOTE

4

Material in this shipment has been inspected at the factory and released to the transportation agency in good condition. When received, a visual inspection of all cartons should be made immediately. Any evidence of rough handling or apparent damage should be noted on the delivery receipt in the presence of the carrier's representative. If damage is found, a claim should be immediately filed against the carrier. This air conditioner is designed for through-the-wall indoor installation only. Installation of this equipment, wiring, ducts, and any related components must conform to current agency codes, state laws, and local codes. Such regulations take precedence over general instructions contained in this manual.



CAUTION

Extreme caution must be taken that no internal damage will result from screws that are drilled into the cabinet.

INTRODUCTION

The FIRST-PAK FPE series air conditioners are selfcontained, electric heating with electric cooling models. The unit design has been certified by Intertek Testing Services for compliance with the Standard of UL 1995 for Safety for Heating and Cooling Equipment. The FPE models are certified to be in compliance with the latest edition of AHRI Standard 210/240.

These installation instructions are intended as a general guide only, for use by an experienced, qualified contractor.



Do not use this air conditioner during any phase of construction.

STORAGE

Equipment should be stored in a clean dry, conditioned area with maximum temperatures up to 120°F [48.89°C] and minimum temperatures to 32°F [0°C]. Units should be stored upright and in an indoor environment. It is recommended to leave packaging on the unit until the installation is to begin.

WARNING

Do not stack more than **FOUR** units for storage purposes. Failure to follow these instructions may result in improper installation, adjustment, service or maintenance, property damage, personal injury or death.

DO NOT operate these units during the construction process. Mechanical components and filters could become clogged with dirt and debris, which can cause damage to the system.

The manufacture does not warrant equipment subjected to abuse.

SHIPPING & PACKAGE LIST



NOTE



Material in this shipment has been inspected at the factory and released to the transportation agency in good condition. When received, a visual inspection of all cartons should be made immediately. Any evidence of rough handling or apparent damage should be noted on the delivery receipt in the presence of the carrier's representative. If damage is found, a claim should be immediately filed against the carrier.

SHIPPING INSTRUCTIONS

The units must remain in the upright position throughout the shipping and handling process to maintain a proper level of oil in the compressor.



NO

Shrink-wrap is located around the unit for protection. Remove before installation.



TRAY COVER

FIGURE 2 – Standard Packaging

PACKAGE LIST

The units will be shipped with the following items:

- 1- FPE (FIRST-PAK) package electric heat/dx cooling unit:
 - A- Shipping bracket
 - B- Screws (4)
 - C- Top mounting bracket
 - D- Screws (4)
- 2- Literature package
 - A- IOM Installation & Operations Manual
 - B- Wall sleeve assembly & installation instructions
 - C- Warranty certificate
- 3- Bushing #WE1063
 - A- Screw (1)

Check the unit for shipping damage; if found, immediately contact the last carrier.

FIRST-PAK - IOM

UNIT INSPECTION CHECKLIST

Complete the inspection procedures below before preparing unit for installation:

- Visually inspect unit for any shipping damage. Damage must be reported immediately to the shipping company to make a claim.
- 2) Ensure that the carrier makes proper notation of any shortages or damage on all copies of the freight bill and completes a common carrier inspection report.
- Verify that unit nameplates on the data label match the sales order or bill of lading (including, unit configuration, size and voltage).
- 4) Immediately before installation, remove unit front panel and verify that all electrical connections are tight and that there are no loose wires.
- 5) Check to make sure that the refrigerant piping is free from any kinks, no visible refrigerant leak and there is no interference between unit piping and sheet metal or electrical wires.
- 6) Check that the blower spins freely within the housing and that there are no obstructions between the wheel and housing. The wheel can sometimes come loose in shipping.
- 7) Check to make sure compressor mounting bolts and nuts are not loose.
- 8) Ensure that the evaporator distributor tubes are not touching one in another and that they are over the drain pan.
- 9) Check the air-coil fins for any damage during shipping.
- 10) Ensure that the shipping brackets and screws are removed from the chassis section. Refer to FIGURE 3 -Standard Packaging with Shipping Brackets - Front View & FIGURE 4 – Standard Packaging with Shipping Brackets -Back View for more information.

11) Inspect the electric heater section:

- a. Check if there's any part damaged or loose.
- b. Check to make sure all wiring connections are tight and there are no loose or broken wires.
- c. Check if the insulation peel off.

Ĵ

NOTE

Check the unit nameplate for correct voltage with the plans before installing the equipment. Also, make sure all electrical ground connections are made in accordance with local code.







FIGURE 4 – Standard Packaging with Shipping Brackets - Back View

UNIT DIMENSIONAL DATA



FIGURE 5 - Unit Dimensions

UNIT PHYSICAL DATA

PHYSICAL DATA												
FPE MODELS	05E1C09A	05E1C12A	07E1C12A	10E1C12A	05E1C18A	07E1C18A	10E1C18A					
UNIT INFORMATION	UNIT INFORMATION											
Compressor Qty/Type	Rotary (1)	Rotary (1)	Rotary (1)	Rotary (1)	Rotary (1)	Rotary (1)	Rotary (1)					
Factory Charge (R410A) lbs. [kg]	3.7 [1.7]	3.9 [1.8]	3.9 [1.8]	3.9 [1.8]	5.7 [2.6]	5.7 [2.6]	5.7 [2.6]					
Compressor Capacitor	40MFD/370V	40MFD/370V	40MFD/370V	40MFD/370V	35MFD/370V	35MFD/370V	35MFD/370V					
Condenser Fan HP [kW]	1/5 [.15]	1/5 [.15]	1/5 [.15]	1/5 [.15]	1/3 [.25]	1/3 [.25]	1/3 [.25]					
Indoor Fan HP [kW]	1/4 [.17]	1/4 [.17]	1/4 [.17]	1/4 [.17]	1/3 [.25]	1/3 [.25]	1/3 [.25]					
Blower Size (D x W) in. [cm]			10	О x 6 [25.4 x 15.2	4]							
Condenser Dimension (H x W) in. [cm]			26	x 23 [66.04 x 58.	42]							
Evaporator Dimension (H x W) in. [cm]			24	x 22 [60.96 x 55.	88]							
Filter Size (H x W) in. [cm]			24	x 24 [60.96 x 60.	96]							
Electric Heater [kW] @240V	5	5	7(2x3.5kW)	10(2x5kW)	5	7(2x3.5kW)	10(2x5kW)					
Max. Static Pressure IWC [pa]				0.5 [125]								
Operating Weight lb. [kg]	273	273	275	275	334	336	336					
Shipping Weight lb. [kg]	293	293	295	295	354	356	356					
		Table	1 - Physical Da	ata								

	PHYSICAL DATA											
FPE MODELS	05E1C24A	07E1C24A	10E1C24A	15E1C24A	05E1C30A	07E1C30A	10E1C30A	15E1C30A				
UNIT INFORMATION												
Compressor Qty/Type	Scroll (1)	Scroll (1)	Scroll (1)	Scroll (1)	Scroll (1)	Scroll (1)	Scroll (1)	Scroll (1)				
Factory Charge (R410A) lbs. [kg]	5.7 [2.6]	5.7 [2.6]	5.7 [2.6]	5.7 [2.6]	5.8 [2.63]	5.8 [2.63]	5.8 [2.63]	5.8 [2.63]				
Compressor Capacitor	35MFD/370V	35MFD/370V	35MFD/370V	35MFD/370V	40MFD/370V	40MFD/370V	40MFD/370V	40MFD/370V				
Condenser Fan HP [kW]	1/3 [.25]	1/3 [.25]	1/3 [.25]	1/3 [.25]	1/3 [.25]	1/3 [.25]	1/3 [.25]	1/3 [.25]				
Indoor Fan HP [kW]	1/2 [.37]	1/2 [.37]	1/2 [.37]	1/2 [.37]	1/2 [.37]	1/2 [.37]	1/2 [.37]	1/2 [.37]				
Blower Size (D x W) in. [cm]				10	О x 6 [25.4 x 15.2	4]						
Condenser Dimension (H x W) in. [cm]				26	x 23 [66.04 x 58.	42]						
Evaporator Dimension (H x W) in. [cm]				24	x 22 [60.96 x 55.	88]						
Filter Size (H x W) in. [cm]				24	x 24 [60.96 x 60.	96]						
Electric Heater [kW] @240V	5	7(2x3.5kW)	10(2x5kW)	15(3x5kW)	5	7(2x3.5kW)	10(2x5kW)	15(3x5kW)				
Max. Static Pressure IWC [pa]					0.5 [125]							
Operating Weight lb. [kg]	345	346	346	349	346	347	347	350				
Shipping Weight lb. [kg]	365	366	366	369	366	367	367	370				
		Tab	le 2 - Physical	Data Continu	ed							

ELECTRICAL DATA

	ELECTRICAL DATA																
MODEL	VOLTAGE-PH-	COMPRESSOR CONDENSO		ENSOR TOR	INDOOR MOTOR		MIN. CIRCUIT AMPACITY			MAX. CIRCUIT PROTECTION			MIN. I	MAX.			
NUMBER	нz							СК	T1	СК	T2	CK	T1	CK	T2	VOLTAGE	VOLTAGE
		RLA LRA	LRA	FLA	нр	FLA	HP	230V	208V	230V	208V	230V	208V	230V	208V		
FPE05E1C09A	208/230-1-60	4.7	26	1.9	1/5	2.3	1/4	27.8	25.4	N/A	N/A	30	30	N/A	N/A	197	252
FPE05E1C12A	208/230-1-60	5.5	26	1.9	1/5	2.3	1/4	27.8	25.4	N/A	N/A	30	30	N/A	N/A	197	252
FPE07E1C12A	208/230-1-60	5.5	26	1.9	1/5	2.3	1/4	37.8	34.4	N/A	N/A	40	35	N/A	N/A	197	252
FPE10E1C12A	208/230-1-60	5.5	26	1.9	1/5	2.3	1/4	52.7	48.0	N/A	N/A	60	50	N/A	N/A	197	252
FPE05E1C18A	208/230-1-60	7.2	38	2.8	1/3	2.8	1/3	28.4	26.0	N/A	N/A	30	30	N/A	N/A	197	252
FPE07E1C18A	208/230-1-60	7.2	38	2.8	1/3	2.8	1/3	38.4	35.0	N/A	N/A	40	40	N/A	N/A	197	252
FPE10E1C18A	208/230-1-60	7.2	38	2.8	1/3	2.8	1/3	53.4	48.6	N/A	N/A	60	50	N/A	N/A	197	252
FPE05E1C24A	208/230-1-60	10.7	55	2.8	1/3	4.1	1/2	30.0	27.6	N/A	N/A	35	30	N/A	N/A	197	252
FPE07E1C24A	208/230-1-60	10.7	55	2.8	1/3	4.1	1/2	40.0	36.7	N/A	N/A	45	40	N/A	N/A	197	252
FPE10E1C24A	208/230-1-60	10.7	55	2.8	1/3	4.1	1/2	55.0	50.2	N/A	N/A	60	60	N/A	N/A	197	252
FPE15E1C24A	208/230-1-60	10.7	55	2.8	1/3	4.1	1/2	55.0	50.2	25.0	22.6	60	60	25	25	197	252
FPE05E1C30A	208/230-1-60	14.1	65	2.8	1/3	4.1	1/2	30.0	27.6	N/A	N/A	35	30	N/A	N/A	197	252
FPE07E1C30A	208/230-1-60	14.1	65	2.8	1/3	4.1	1/2	40.0	36.7	N/A	N/A	45	40	N/A	N/A	197	252
FPE10E1C30A	208/230-1-60	14.1	65	2.8	1/3	4.1	1/2	55.0	50.2	N/A	N/A	60	60	N/A	N/A	197	252
FPE15E1C30A	208/230-1-60	14.1	65	2.8	1/3	4.1	1/2	55.0	50.2	25.0	22.6	60	60	25	25	197	252
							Table 3	- Electric	al Data								

PERFORMANCE

		C00	LING		HEATING			
	CEM	P+u /b	CEED	с/т	24	0V	208V	
FPE MODELS	CFIVI	BLU/N	JEEN	3/1	KW	Btu/h	KW	Btu/h
FPE05E1C09A	350	9500	12.5	0.78	5	17060	3.8	12814
FPE05E1C12A			13.0		5	17060	3.8	12814
FPE07E1C12A	460	12000		0.75	7	23884	5.3	17940
FPE10E1C12A					10	34120	7.5	25628
FPE05E1C18A	630	17500	13.0	0.74	5	17060	3.8	12814
FPE07E1C18A					7	23884	5.3	17940
FPE10E1C18A					10	34120	7.5	25628
FPE05E1C24A		22200	13.0	0.82	5	17060	3.8	12814
FPE07E1C24A	740				7	23884	5.3	17940
FPE10E1C24A	740	22200			10	34120	7.5	25628
FPE15E1C24A					15	51180	11.3	38442
FPE05E1C30A					5	17060	3.8	12814
FPE07E1C30A	040	27000	12.0	0.75	7	23884	5.3	17940
FPE10E1C30A	940	27000	12.0	0.75	10	34120	7.5	25628
FPE15E1C30A					15	51180	11.3	38442
		Table 4 - P	Performance	ce				

INSTALLATION

REQUIREMENTS

Follow manufacturer's installation instructions, as well as local and municipal building codes. In addition, the installation shall conform to the following Fire Protection Association (NFPA) Standards:

- NFPA No. 90A Standard for Installation of Air Conditioning and Ventilation Systems
- NFPA No. 90B Standard for Installation of Residence Type Warm Air Heating and Air Conditioning Systems.

This unit is approved for installation clearance to combustible material as stated on the unit rating plate. However, stated minimum clearances to combustibles may be inadequate for future accessibility and service needs which must be considered when planning of the installation.

INSTALLATION PRECAUTIONS



Equipment when installing and servicing these units.

WARNING

Use multiple people when moving and installing these units. Failure to do so could result in injury or death.

CAUTION

Contact with metal edges and corners can result injury. Protective gloves should be worn when handling. Exercise caution when installing and servicing unit.

Observe the following precautions for typical installation:

- Always use proper tools and equipment
- No wiring or any work should be attempted without first ensuring the unit is completely disconnected from the power source and locked out. Also, verify that a proper permanent and uninterrupted, ground connection exists prior to energizing power to the unit.
- Review unit nameplate and wiring diagram for proper voltage and control configurations. This information may vary from unit to unit.

UNIT LOCATION

This product is certified for through-the-wall, indoor, upflow vertical position installation only. This appliance is not design certified for installation in mobile homes, recreational vehicles, or outdoors. A First Company approved wall sleeve must be used to install the unit.

Do not install directly on carpeting, tile, or other combustible material other than wood flooring.

The Installation must conform with local building codes or, in the absence of local codes, to the Protection Association Standards NEPA. No. 90A and NEPA. No. 90B.





UNIT CLEARANCE REQUIREMENTS

The interior of the unit may be installed with zero clearances to adjacent combustible surfaces. This unit shall not be installed directly on carpeting, tile, or other combustible material, other than wood flooring.

Service clearance must be provided for future maintenance and service. A minimum of 32" [81.28cm] open area must be left unobstructed in front of the access panels.

The grille side must be kept free from any obstructions to air flow. The unit must be installed at least 4 feet [1.2192m] from electric meters, gas meters, regulators, and relief equipment.



FIGURE 7 – Required Exterior Building Clearance

CLEARANCE REQUIREMENTS										
MINIMUM CLEARANCE INCHES CM										
Horizontal distance between units	12	30								
Vertical distance between units	60	152								
Distance above ground level	6	15								
Distance above finished floor	6	15								
Distance above a garage floor	18	46								
Table 5- Clearance Requirements/	'Dimensions	S								

An air conditioner installed in a garage must also be protected from damage by vehicles.



FIGURE 8 – Interior Clearance Requirements



with a lintel for wall support. Wall openings must be flashed and sealed. The unit must be level, front to back, side to side.

Refer to **CLEARANCE REQUIREMENTS** section in this manual for more information.

WALL SLEEVE INSTALLATION

Refer to installation instruction packed with the wall sleeve to assemble and mount into the wall. Before unit installation, make sure sleeve components are not damaged; drain line is not obstructed and is leak free.

Check all seals to ensure that they are in position and undamaged. Ensure that the wall sleeve is sloped toward the exterior of the building (FIGURE 9 - Wall Sleeve Mounting). Securely fasten the Architectural grille to the front of the sleeve using the supplied hardware.



FIGURE 9 - Wall Sleeve Mounting

IMPORTANT

After sleeve installation, ensure that the gap in-between the wall and seal is insulated and is in contact with the sleeve sides.

IMPORTANT

Make sure a high grade non-hardening sealant approved for exterior use has been applied between edge of the sleeve and the structure, on the inside and outside walls, to prevent air and water from migrating inside (FIGURE 9 -Wall Sleeve Mounting).

REAR INSTALLATION & DIMENSIONS



Sleeve dimensions vary based on model purchased.

The inside of the unit can be surrounded by a closet with minimum clearance to heater section match to 0" clearance on the sides, 2" [5.08cm] clearance from the top, and 1" [2.54cm] from the front and the plenum. Enough clearance should be provided for installing field wiring. Do not install directly on any combustible material (such as carpet, tile, etc.) other than wood flooring.

UNIT SUPPORT

The First Pak wall sleeve is not intended or designed to provide complete support for the First Pak unit. Additional support is required. A field constructed platform may be used for this purpose and may also be constructed to provide a means of attaching the return air duct.

PLYWOOD INSTALLATION

Support base construction should be built as below in FIGURE 11 - Unit Support & Alignment. It must be fabricated with plywood, framing lumber and/or any preapproved sheet metal construction material. FIGURE 11 -Unit Support & Alignment is showing alignment of the platform top with the base panel of the wall sleeve.

- Minimum height of platform = 8" [20.32cm]
- Recommended platform width = 29" [73.66cm]
- Recommended platform depth = 16" [40.64cm]

Refer to FIGURE 11 - Unit Support & Alignment.

Things to consider prior to build the support structure:

- 1. Accurately measure the unit and choose a strong building material for the support structure.
- 2. It is recommended that for leveling purposes the unit should be well supported.
- 3. If additional vibration isolation material is required, non-combustible material **MUST** be used.
- Ensure that the platform connection to FIRST-PAK Return Air Opening can fit an 8" x 24" [20.32cm x 60.96cm] duct. The FIRST-PAK unit must be aligned with return air opening on the unit base.
- 5. Ensure the support structure and the Wall Sleeve provide a secure, fixed, and leveled position. This allows a provision of bringing return air via ducting to the space under the unit.



FIGURE 11 - Unit Support & Alignment





The sleeve is not intended as the sole support for the unit. An additional support must be provided near the return opening on the unit for adequate support. The use of vibration isolation material between the unit and the support is recommended.

PACKAGED UNIT INSTALLATION



FIGURE 12 - FIRST-PAK Unit Installation

Ĵ

A

i

Locate the unit in an area that provides minimum clearance to all service access panels. Consider all additional clearances needed for water connections, electrical connections, duct connections and sufficient return airflow.

ΝΟΤΕ

IMPORTANT

These units are for indoor installation ONLY!

i

NOTE

Do not locate unit in areas subject to freezing temperatures or where high humidity levels could cause cabinet condensation. FIRST-PAK units are available in right and left hand configurations. Units should be mounted on the sleeve with a pitch to the outside of the building. Insulation is installed in indoor equipment to provide a barrier between outside air conditions surrounding the unit and the varying conditions inside the unit. If the insulating barrier is damaged, the surrounding ambient air will affect the inside surface temperature of the cabinet; this may lead to sheet metal corrosion and subsequently, component failure.

IMPORTAN

NT

Damaged insulation must be repaired or replaced before the unit is placed back into operation. Insulation loses its insulating properties when wet, damaged, separated or torn.

The installer must adhere strictly to all local and national code requirements pertaining to the installation of this equipment including the cabinet, discharge plenum and connecting ducts. All units are designed for indoor use only, and are agency listed for installation with clearances specified on the product rating plate.



proper power supply.

1. Remove the four shipping brackets holding the unit to the shipping pallet and remove unit from the shipping pallet.

NOT

The top mounting bracket must be attached to the FIRST-PAK unit.

 Attach the bracket to the FIRST-PAK unit and the wall sleeve using the screws supplied with the wall sleeve. Refer to FIGURE 13 – below.



- 3. Ensure that properly sized ductwork is in place to mate to the connections on the FIRST-PAK.
- 4. Remove front access panel and verify all electrical connections are secure and check the condenser fan to see it turns freely.

1



For shipping purposes the supply flanges are shipped flat. The discharge duct flanges must be bent up at a 90° angle.

5. If an air filter is to be applied to the unit remove lower front access panel to replace filter. (FIGURE

17 – Air Filter Location). Place the filter into the filter bracket.

- 6. Ensure that the wall sleeve is installed squarely and is secured before installing the unit.
- Inspect the sleeve seal, which is supplied with the sleeve, to ensure that it is properly secured and aligned (see FIGURE 13 – Wall Sleeve Seal).
- 8. Slide the FIRST-PAK unit toward the sleeve seal until the sleeve and cabinet brackets are nested and almost making contact.
- 9. Center the FIRST-PAK unit in the sleeve.
- 10. Use screw fasteners to attach the cabinet bracket to wall sleeve.



FIGURE 14 – Top Bracket Installation on Sleeve

- 11. Use a high-grade non-hardening sealant to close any gaps that may exist between the seal and the wall of the sleeve.
- 12. Check that the unit is completely settled on all four sides against the wall sleeve seals.

CAUTION

If unit is not sealed properly, water and/or outside air will infiltrate into the closet, and can cause improper unit operation and may cause damage to the unit and/or property.

DUCTWORK

IMPORTANT I

Both supply and return air ducts must be ducted to the

unit.

Ţ

IMPORTANT

The supply duct connection must be sized to a minimum of the same size as the unit discharge air opening.

IMPORTANT

All ductwork must be installed in accordance with National Fire Protection Assoc. Codes 90A and 90B.

DISCHARGE DUCTING

Discharge ductwork should be sized and constructed in accordance with industry best practices and standards.

Insufficiently sized ductwork will cause low supply airflow, which could cause low cooling performance, liquid flood back to compressor and condensate in the cabinet. In heating operation, low airflow could cause the heater autoreset limit switch cycle on and off, which would reduce the longevity of heating element. Excessive airflow may result in a noisy duct system and could lower heating supply temps to an uncomfortable level. Unit external static cannot be more than 0.5 in. w.c.

Ductwork should be adequately insulated to prevent condensation and to minimize heat loss within the duct system. A flexible connector is recommended for supply air connections on metal duct systems to limit noise.

RETURN AIR DUCTING

Return air ducting can be brought in through a wall grille or opening and then to the unit. The return duct should be sealed to the return air opening on the bottom of the unit and must terminate inside of the indoor space. It is recommended to use duct material with acoustically lined insulation for sound attenuation. The return duct must be sized for a 24"x 8" [60.96cm x 20.32cm] opening and it is recommended to use sheet metal screws



FIGURE 15 – Unit Return Ducting

CONDENSATE DRAINAGE

Condensate drain lines must be properly installed with adequate slope away from unit to ensure proper drainage. A minimum trap of 1.5 inches [3.81cm] must be installed to isolate the negative pressures of the drain pan from the drain line. Refer to for schematic information on the condensate drain lines. Drain line should be insulated to prevent condensate dropping to the ground and duct.



FIGURE 16 - Condensate Drain Layout

AIR FILTER

All indoor return air must be filtered. The preferred methods are:

- 1. Use the factory supplied filter kit which attaches to the inlet of the evaporator.
- Use the filter kit supplied with the access panel which accepts an 24 inch x 24 inch x 1 inch [60.96cm x 60.96cm x 2.54cm] throwaway type of filter.
- 3. Install a filter in the return grille mounted in the wall. Any field installation of an air filter, means must be provided, for us of a disposable filter which is no smaller than the face area of the evaporator coil.
- 4. Located in the return air opening, all indoor return air must be filtered.
- 5. A filter of same size or a filter with equivalent pressure drop must be used at all time.
- 6. A washable filter is provided with the unit and can be easily removed by the consumer.
- 7. If a return duct is installed, provisions must be to accommodate filter servicing.
- 8. It's recommended to clean filter at least 3 times in summer and winter season or more if needed.
- 9. Filter can be cleaned by dusting the filter by shaking or vacuuming, this filter can also be washed with some soap and water and replace once it's dry is recommended.

10. The washable filter can be used or replaced with a disposable filter of the same size as mentioned in the table provided to size the filter.

AIR FILTER MINIMUM DIMENSIONS							
Model Series	Minimum Area						
FPE**E1****	576 sq. inches						
	[0.3716 sq. meter]						
Table 6 - Air Filter Minimum Dimensions							



Do not operate this equipment without an air filter.



ELECTRICAL

HIGH VOLTAGE



G

FPE15E1C24A *** model requires two separated power resource supplying the unit.

WARNING

Use copper conductors only. Install all parts and panels before operation of unit. Failure to follow these warnings can result in injury or death.

All wiring must comply with local and national code requirements. Units are provided with wiring diagrams and nameplate data to provide information required for necessary field wiring.

These units are provided with a class 2 transformer for 24VAC control circuits. Should any add-on accessory or component also have a class 2 transformer furnished, care must be taken to prevent interconnecting outputs

FIRST-PAK - IOM

of the two transformers by using a thermostat with isolating contacts.

WARNING

Connect ground wire to ground terminal marked "GND". Failure to do so can result in injury or death.

CAUTION

Any device that has been furnished by the factory for field installation must be wired in strict accordance with the associated wiring diagram. Failure to do so could damage components and void warranties.

Unit with 5kW, 7kW or 10kW heaters has a knockout hole on the top panel for field line voltage connection. Unit with 15kW heater has two knockout holes for field line voltage connection. The bigger one is for power supply connected to the 60A circuit breaker in the unit. The smaller knockout hole is for power supply connected to the 30A circuit breaker in the unit. See FIGURE 18, FIGURE 19 and FIGURE 20. The ground wire must be connected to the ground screws with gold disk.







FIGURE 18 - Cabinet with 5KW, 7KW, 10KW Heaters



FIGURE 20– Heater Electric Panel Layout

FIRST-PAK - IOM

208-230 VOLT OPERATION

All 208-230 Volt units are factory wired for 230 Volt operation. For 208 Volt operation,

moving/changing/rewiring the line voltage tap on the 24 Volt control transformer is required. See note 3 on the wiring diagram for instruction.

LOW VOLTAGE

THERMOSTAT

A standard 24 VAC single state heating and cooling thermostat is required to control this unit. A thermostat with a "C" common terminal is preferred. Thermostat should be connectted to the control wire through the LOW VOLTAGE hole on the top panel shown in FIGURE 18 and FIGURE 19. Thermostat connections and their functions are below in FIGURE 21 - Thermostat Connections as follows:

	THERMOSTAT CONNECTIONS KEY									
Abbr.	Color	Function								
Υ –	Yellow	Compressor Contactor								
С —	Brown	Transformer 24VAC Common								
W –	White	Call for Heating								
G –	Red	Evaporator Blower								
R —	Green	Transformer 24VAC Hot								
	Table 7 - Thermostat Connections Key									



FIGURE 21 - Thermostat Connections

THERMOSTAT INSTALLATION

The Thermostat should be located on an interior wall in a larger room, away from supply duct draft. Position the thermostat back plate against the wall so that it appears level and so the thermostat wires protrude through the middle of the back plate mounting holes and drill holes with a 3/16" [5mm] bit. Install supplied anchors and secure plate to the wall. Thermostat wire must be 18 AWG wire.

CONTROLS

COOLING OPERATION

STEADY STATE COOLING

When the unit is given a "Y" input the unit will operate in steady state cooling mode. The compressor will immediately come on after a "Y" input. After a 5s time delay the indoor fan will be energized. The system will remain in steady state operation as long as the "Y" input is provided to the unit.

The "Y" signal has priority over the both the "W" and "G" signals. If both "Y" and "W" are called, the call for cooling has priority. The heat cycle is interrupted as if the call for heat had terminated and the call for cooling proceeds as normal.

When the "Y" input is removed from the system the control immediately energizing the compressor contactor. The indoor blower de-energizes after a cooling off delay period of 90s.

CONTINUOUS FAN OPERATION

When the unit is given a "G" input, without an additional "Y" or "W" call, the unit will operate in continuous fan operation mode. The indoor fan is energized with the "G" call after a .25s delay. The fan remains energized as long as the "G" input is provided to the unit without a "Y" or "W".



FIGURE 22 - Cooling Sequence of Operations

LOW AMBIENT COOLING OPERATION

The unit is designed to operate down to 35°F outside air ambient. For cooling operation at below 35°F outside air ambient, low ambient kit is required.

CONTROLS CONTINUED

BLOWER CONTROL

The FPE units are equipped with a direct drive indoor blower motor. FPE**E1C09A and FPE**E1C12A have a blower motor with 4 speeds. 2 speeds reserved for heating, 1 tap reserved for cooling, and 1 speed reserved for ventilation. All other models have 5 fan speeds, with 2 fan speeds reserved for heating, 2 fan speeds reserved for cooling, and 1 speed reserved for ventilation. The cooling fan speed selection wire and heating fan speed selection wires are located on separate wires. In order to change the fan speed selection wire to the desired tap. See wiring diagram located on the unit.

Refer to Table 7 – BLOWER PERFORMANCE DATA and Table 8 – BLOWER PERFORMANCE DATA – CONTINUED for information on the select speed changes for heat and cool mode.



FIGURE 23 - Blower Control Tap

WARNING



The unit is designed to operate at maximum 0.5 in.w.c external static pressure. Running at more than 0.5 in.w.c E.S.P may cause unit not working properly and even damage the unit. For applications requiring higher static operation, please contact factory or the manufacture's sales reps.



NOTE

High efficiency brushless DC motors are wired with power applied at all times, see illustration above. Low voltage thermostat demand and board algorithms will control its use.

Unit Model

FPE05E1C09A

	T4 ^C	374	331	285	221	
	T1	317	259	214	140	98
	T2 ^H	541	500	466	428	386
FPEUSEICIZA	Т3	630	591	557	529	496
	T4 ^c	466	450	408	363	323
	T1	321	260	197	149	108
50507516124	Т2 ^н	614	577	542	521	488
FPEU/EICIZA	Т3	691	656	624	595	567
	T4 ^C	486	445	401	354	314
	T1	321	260	197	149	108
EDE1051012A	Т2 ^н	691	656	624	595	567
FFEIUEICIZA	Т3	614	577	542	521	488
	T4 ^C	486	445	401	354	314
	T1	442	328	263	233	204
FPE05E1C18A	Т2 ^н	747	722	688	665	639
	Т3	876	851	822	798	770
	T4 ^c	667	648	618	580	552
	Т5	713	695	666	632	606
	T1	436	323	257	231	201
	Т2 ^н	741	715	682	659	639
FPE07E1C18A	Т3	869	846	815	793	763
	T4 ^c	662	642	609	575	552
	T5	707	689	657	628	606
	T1	436	323	257	231	201
	Т2 ^н	929	897	865	841	803
FPE10E1C18A	Т3	807	785	753	733	709
	T4 ^c	662	642	609	575	552
	Т5	707	689	657	628	606
	T1	559	482	425	387	325
	T2 ^H	820	772	741	702	674
FPE05E1C24A	ТЗ	978	947	916	879	855
	T4 ^C	766	715	677	637	611
	Т5	919	882	853	816	791
		Table 8	BLOWER PERFORMAN	CE DATA		

BLOWER PERFORMANCE

0.2

207

500

591

SCFM @ External Static Pressure (in.w.c)

0.3

168

466

557

0.4

87

428

529

CONTROLS CONTINUED

Blower Speed Tap

Τ1

т2^н

тз

0.1

278

541

630

0.5

386

496

CONTROLS CONTINUED

	BLOWER PERFORMANCE								
11	Blown Crowd Tra		SCFM @ I	External Static Pressur	e (in.w.c)				
Unit Model	Blower Speed Tap	0.1	0.2	0.3	0.4	0.5			
	T1	543	477	424	384	325			
	Т2 ^н	808	765	738	694	664			
FPE07E1C24A	Т3	973	937	906	870	844			
	T4 ^C	768	720	688	647	620			
	T5	908	871	843	804	780			
	T1	543	477	424	384	325			
	T2 ^H	840	798	768	729	705			
FPE10E1C24A	Т3	973	937	906	870	844			
	T4 ^C	768	720	688	647	620			
	Т5	908	871	843	804	780			
	T1	517	472	422	387	336			
	T2 ^H	1050	1003	958	906	848			
FPE15E1C24A	Т3	931	899	877	846	823			
	T4 ^C	773	742	713	690	666			
	T5	889	858	831	802	779			
	T1	559	482	425	387	325			
	T2 ^H	820	772	741	702	674			
FPE05E1C30A	T3	978	947	916	879	855			
	T4 ^C	941	906	878	840	814			
	Т5	978	947	916	879	855			
	T1	543	477	424	384	325			
	T2 ^H	808	765	738	694	664			
FPE07E1C30A	ТЗ	973	937	906	870	844			
	T4 ^C	941	906	878	839	814			
	Т5	973	937	906	870	844			
	T1	543	477	424	384	325			
	T2 ^H	840	798	768	729	705			
FPE10E1C30A	T3	973	937	906	870	844			
	T4 ^C	941	906	878	839	814			
	T5	973	937	906	870	844			
	T1	517	472	422	387	336			
	T2 ^H	1050	1003	958	906	848			
FPE15E1C30A	Т3	931	899	877	846	823			
	T4 ^C	948	913	883	847	826			
	T5	1050	1003	958	906	848			

NOTE:

. Airflow data shown is with dry coil at 70°F DB EAT with standard 1" air filter.

Unit is not recommended in the shaded area.

For models with four speed taps, tap T1 is for ventilation. T2 and T3 are for heating operation. T4 is for cooling operation.

. For models with five speed taps, tap T1 is for ventilation. T2 and T3 are for heating operation. T4 and T5 are for cooling operation.

Superscript C indicates factory-set default cooling tap. Superscript H indicates factory-set default heating tap.

Table 9 BLOWER PERFORMANCE DATA -CONTINUED

CONTROLS CONTINUED

HEATING OPERATION

When the thermostat calls for heating, the "W" signal is energized. The evaporator coil blower starts operation immediately. The heater would not start until 1 to 10 seconds delay.

TEMPERATURE LIMIT CONTROL

The electric heater is equipped with auto-reset temperature limit switch and non-resettable fuse link. In the case of supply temperature too high caused by abnormal situations such as low airflow due to dirty clogged air filter or air leak or no airflow due to failed motor, the auto-reset limit switch will interrupt the power to the heating elements. Once the heating elements cool down, the limit switch will close and the power to the heating elements will be restored. The heater will resume the operation. If the auto-reset switch is permanently closed, the non-resettable fuse link will activate to cut off the power to the heating elements permanently. The heater will stop working until the fuse link is replaced by a certified technician or agency.



FIGURE 24 – Auto-Reset Temperature Limit Switch



LOCATION OF MAJOR COMPONENTS





REPLACEMENT PARTS

PART NAME	PART #	MOD	EL USE	PART NAME	PART #	MOD	EL USE
Compressor	CO102GKS	FPE05E1C09A				FPE05E1C18A	FPE15E1C24A
Comprossor	CO120KAD	FPE05E1C12A	FPE10E1C12A			FPE07E1C18A	FPE05E1C30A
Compressor	CUIZUNAD	FPE07E1C12A		Condenser Coil	321-362	FPE10E1C18A	FPE07E1C30A
Comprossor	CO151CIS	FPE05E1C18A	FPE10E1C18A	Assembly	521-502	FPE05E1C24A	FPE10E1C30A
Compressor	CO131013	FPE07E1C18A				FPE07E1C24A	FPE15E1C30A
Comprossor	CO21K	FPE05E1C24A	FPE10E1C24A			FPE10E1C24A	
Compressor	COZIK	FPE07E1C24A	FPE15E1C24A	Expansion Valve	CP8312	FPE05E1C09A	
		FPE05E1C30A	FPE15E1C30A	Expansion Valve	CP8308	FPE05E1C12A	FPE10E1C12A
Compressor	CO297	FPE07E1C30A			CF 8508	FPE07E1C12A	
		FPE10E1C30A		Expansion Valve	CP8309	FPE05E1C18A	FPE10E1C18A
		FPE05E1C18A	FPE07E1C24A		CI 0303	FPE07E1C18A	
Condenser Fan		FPE07E1C18A	FPE10E1C24A	Expansion Valve	CP8310	FPE05E1C24A	FPE10E1C24A
Motor	WDN055240A	FPE10E1C18A	FPE15E1C24A		CI 0510	FPE07E1C24A	FPE15E1C24A
		FPE05E1C24A		Expansion Valve	CP8311	FPE05E1C30A	FPE10E1C30A
Condenser Fan		FPE05E1C30A	FPE10E1C30A		CI 0311	FPE07E1C30A	FPE15E1C30A
Motor		FPE07E1C30A	FPE15E1C30A	Air Filter	AF2424	All FIRST-PAK Mo	odels
Condenser Fan	MDR020240R	FPE05E1C09A	FPE07E1C12A	5kW Heater	310-641-1	FPE05E1C**A	
Motor		FPE05E1C12A	FPE10E1C12A	Assembly	510 011 1		
Evaporator Blower	MDP025115	FPE05E1C09A	FPE07E1C12A	7kW Heater	310-641-2	FPE07E1C**A	
Motor	11101 023113	FPE05E1C12A	FPE10E1C12A	Assembly	510 011 2		
Evaporator Blower	MDX033240	FPE05E1C18A	FPE10E1C18A	10kW Heater	310-641-3	FPE10E1C**A	
Motor		FPE07E1C18A		Assembly	510 011 5		
	MDX050240	FPE05E1C24A	FPE10E1C24A	15kW Heater	310-641-4	FPE15E1C**A	
Evaporator Blower		FPE07E1C24A	FPE15E1C24A	Assembly	510 011 1		
Motor		FPE05E1C30A	FPE10E1C30A	Heating Element	115-3-2	FPE05E1C**A	FPE10E1C**A
		FPE07E1C30A	FPE15E1C30A	Assembly 5kW	110 0 2	FPE15E1C**A	
		FPE05E1C09A	FPE05E1C24A	Heating Element	115-3-10	FPF07F1C**A	
		FPE05E1C12A	FPE07E1C24A	Assembly 3.75kW	110 0 10		
		FPE07E1C12A	FPE10E1C24A	Auto-Reset Limit	F144	All FIRST-PAK w/	Electric Heat
Fan Blade	FB20305	FPE10E1C12A	FPE15E1C24A	Switch		Models	
		FPE05E1C18A		Non-resettable	115-38-1	All FIRST-PAK w/	Electric Heat
		FPE0/E1C18A		Fuse Link	115 50 1	Models	
		FPEIDEICI8A		Contactor	E1323777	All FIRST-PAK Mo	dels
High Pressure	E2125	AII FIRST-PAK MO	dels	Transformer	E1372	All FIRST-PAK Mo	dels
SWITCH	0000050		-l - l -	30A Circuit Breaker	E1771	FPE15E1C24A	FPE15E1C30A
Fliter Drier	CP20053	AII FIRST-PAK MO	dels	60A Circuit Breaker	E1801	FPE15E1C24A	FPE15E1C30A
Evaporator Coll	321-363	FPEUSEICU9A	FPEU/EICIZA	C	5140	FPE05E1C**A	FPE07E1C**A
Assembly		FPEUSEICIZA	FPEIUEICIZA	Sequencer	E142	FPE10E1C**A	FPE15E1C**A
		FPEUSEICI8A	FPE15E1C24A	Sequencer	E143	FPE07E1C**A	FPE10E1C**A
Evaporator Coil		FPEU/EICI8A	FPEUSEIC3UA	Sequencer	F1433	FPE15E1C24A	FPE15E1C30A
	321-361	FPEIUEICI8A	FPEU/EIC3UA	Capacitor	E1502	EDE**E1C18A	EDE**E1C24A
Assembly				Capacitor	E1502 E1508		
			FREIDEIC30A	Capacitor			FFE EICIZA
Condonaer Cail				4		FPETTEIC3UA	
	321-364						
ASSEILINIY	1	FFEUUJEIUIZA	LLEINEICIZA	1			

Table 10 – Replacement Parts

FIRST-PAK - IOM



FIGURE 29 – FPE07E1C12A, FPE10E1C12A ROTARY 208-230V ECM Wiring Diagram



Þ

FIRST-PAK - IOM

FIRST-PAK - IOM

WIRING DIAGRAMS





FPE05E1C24A SCROLL 208-230V ECM

WIRING DIAGRAMS



FIGURE 33— FPE07E1C24A, FPE10E1C24A 208-230V ECM Wiring Diagram



FIRST-PAK - IOM

WIRING DIAGRAMS



FIGURE 34 – FPE15E1C24A SCROLL 208-230V ECM Wiring Diagram



FIGURE 35- FPE05E1C30A 208-230V ECM Wiring Diagram





FIGURE 36 – FPE07E1C30A , FPE10E1C30A SCROLL 208-230V ECM Wiring Diagram



FPE SERIES – IOM (REV. A 03/22)



STARTUP INSTRUCTIONS

PRE-STARTUP CHECKS:

WARNING

Electrically ground the unit. Connect ground wire to ground lug. Failure to do so can result in injury or death.

CAUTION

Wire any field installed device such as a fan switch or thermostat furnished by the factory in strict accordance with the wiring diagram supplied with the unit. Failure to do so could result in damage to components and will void all warranties.

Before start-up, thoroughly check all the components. Optimal operation of equipment requires cleanliness. Often after installation of the equipment, additional construction activities occur. Protect the equipment from debris during these construction phases.

PRIOR TO THE STARTUP OF THE UNIT:

- 1. Ensure supply voltage matches nameplate data.
- 2. Ensure the power cable is connected to the unit and the ground cable is connected to the ground lug of heater.
- 3. With the power off, check blower wheel set screws for proper tightness and that the blower wheel rotates freely.
- 4. Ensure unit will be accessible for servicing.
- 5. Ensure condensate line is properly sized, run, trapped, pitched and tested.
- 6. Ensure all cabinet openings and wiring connections have been sealed.
- 7. Ensure clean filters are in place.
- 8. Ensure all access panels are in place and secured.
- 9. Make sure that all electrical connection are tight and secure.
- 10. Check the electrical overcurrent protection and wiring for the correct size.

STARTUP INSTRUCTIONS CONTINUED

- 11. For 208 voltage power, make sure the line voltage tap on the 24 Volt control transformer has been moved and rewired.
- 12. Verify that the low voltage wiring between the thermostat and the unit matches the wiring diagram.
- 13. Make sure the supply duct and return duct have been installed properly and sealed well.
- 14. Models with 15kw heater (FPE15EC***) should have two separate power supplies connecting to the unit. Make sure each line voltage is connected to the correct circuit breaker in the unit.

UNIT STARTUP:

- 1. Ensure that power is connected to the unit and the local disconnect is switched to ON position.
- 2. Turn on the power.
- 3. Check that there is 24V from the control transformer. The controller module LED should light up.

COOLING

- 1. Turn the thermostat system switch to "COOL" and the fan switch to "AUTO" position.
- 2. Set the temperature below room temperature.

HEATING

- 3. Turn the thermostat system switch to "HEAT" and the fan switch to "AUTO" position.
- 4. Set the temperature above current room temperature.

STARTUP & PERFORMANCE CHECKLIST INSTRUCTIONS

Follow the Startup and Performance Checklist in Figure 50 and Figure 51 to check if the temperature and refrigerant pressure are normal, and if compressor and fan are running properly without abnormal sound. The warranty may be void unless the checklist is completed and returned to the warrantor. If the unit is not installed properly, the warranty will be void as the manufacturer can't be held accountable for problems that stem from improper installation.

TROUBLESHOOTING

HEATING					
PROBLEM	POSSIBLE CAUSE	CHECKS & CORRECTIONS			
	Power is not turned on	Turn on the power			
	Wiring is incorret or loose	Check the wiring with wiring diagram and check if the wiring connection is loose			
NO HEAT	Thermostat setpoint is too low	Set the temperature higher than currrent room temperature			
	Fuse is broken	Replace fuse			
	No airflow	Check if the blower is on or if there's any obstruction in the duct			
	Heater fuse link is broken	Replace fuse link			
	Thermostat setpoint too high caused feeling hot in room	Set the temperature lower			
	Low airflow caused by dirty or clogged air filter	Clean or replace air filter			
TOO HIGH	Low airflow caused by too high external static	Check if supply duct and return duct are sized properly or if there's any obstruction in the duct			
	Power voltage is too high	Max. voltage for operation is 252V			
	Current speed tap is not high enough	Change heating speed tap to the optional heating tap with higher torque value			
HEATER TURNED ON BUT STOP WORKING QUICKLY	Fuse broken	Check if fuse is sized correctly or power cable loose			
	Heating elements are not all on (for 7kW, 10kW and 15kW heaters)	Check if the protection devices (auto-reset switch and nonresetable fuse link) of heating element activated			
AIR NOT WARA	Power voltage is too low	Min. voltage for operation is 187V			
	Air leak in the unit or in duct	Check If the ducts are sealed well			
	Thermostat setpoint is too low	Set the temperature higher			
Table 11 Heating Troubleshooting Table					

TROUBLESHOOTING CONTINUED

COOLING

PROBLEM	POSSIBLE CAUSE	CHECKS & CORRECTIONS			
	Power supply off	Apply power; close disconnect.			
	Blown Fuse	Replace fuse or reset circuit breaker. Check for correct fuses.			
	Voltago supply low	If voltage is below minimum voltage specified on unit data plate,			
	voltage supply low	contact lower power company.			
	Wiring	Check if there's any wire loose or broken			
DOLS NOT KON		Set the fan to "ON", the fan should run. Set thermostat to "COOL" and			
	Thermostat	lowest temperature setting, the unit should run in the cooling mode. If			
	mermostat	neither the blower nor compressor run with the thermostat set to			
		"COOL", check that the unit is wired correctly.			
	Thermostat	Check setting, calibration and wiring.			
	Wiring	Check for loose or broken wires at compressor, capacitor or			
	vvii ing	contractor.			
OPERATES BLIT	Compressor overload open	If the compressor is cool and the overload will not reset, replace the			
COMPRESSOR		compressor.			
DOFS NOT RUN	Compressor motor	Internal wiring grounded to the compressor shell. Replace compressor.			
201011011	grounded	If compressor burnout, install new filter dryer.			
	Compressor windings open	After compressor has cooled, check continually of compressor			
	compressor windings open	windings. If the windings are open, replace the compressor.			
	Condenser has no airflow	Condenser fan motor bad or wire loose.			
	Condenser coil too dirty	Clean condenser coil			
UNIT OFF ON	Outside ambient	Unit is designed to run up to 115°F outside ambient temperature.			
HIGH PRESSURE	temperature is too high	Consult factory for application with higher ambient temperature.			
CONTROL	Refrigerant charge	The unit is overcharged with refrigerant. Reclaim refrigerant, evacuate			
		and recharge with factory recommended charge.			
	High pressure switch	Check for defective or improperly calibrated high-pressure switch.			
Table 12 – Cooling Troubleshooting Table					

Ą

MAINTENANCE & SERVICE - HEATING

The heating module is a single assembly composed of heating elements, first protection device (auto-reset temperature switch), second protection device (non-resettable fuse link), sequencers and power distribution block (unit with 15kW heaters has two circuit breakers instead of power distribution block). See **Figure 23 Electric Heater Assembly**.

The heating module should be inspected annually (minimum) before heating season starts by a qualified technician or agency. Power to the unit MUST be turned off and disconnected before serving.

ELECTRIC SHOCK, FIRE OR

ELECTRIC SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings operation, serious injury, death or property damage.

Improper servicing could result in dangerous operation death or property damage.

- Before servicing, disconnect all electrical power to the unit.
- When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.
- Verify proper operation after servicing.

MAINTENANCE & SERVICE – HEATING CONTINUED

FUSE LINK REPLACEMENT

5kW heater has one heating element. 7kW and 10kW heaters have two heating elements. 15kW heater has three 5kW heating elements. Each heating element is installed with one non-resettable fuse link (see page 26). If the fuse link is broken, order the replacement part from company (see Table 9 in page 28), and follow below procedures to replace it.

- 1) Turn off electrical power to the unit
- 2) Remove front top panel from the unit. See FIGURE 36 Front Top Panel Removal.



FIGURE 39 – Front Top Panel Removal

 Disconnect wires from the heating element whose fuse link is broken. And remove screws from the mounting plate.



Disconnect the wire to remove the heating element

4) Take out the mounting plate with heating element. Replace the broken fuse link.



MAINTENANCE & SERVICE – HEATING CONTINUED

5. Put the heating element back to the unit, install the screws and connect the wires.

NOTE: When putting the heating element back to the unit, make sure the rod is inserted into the hole on the heater support panel. The window covered by the blank mounting plate is to help to locate the hole when interesting the heating element.



VIEW PORT (THIS WINDOW IS USED TO HELP LOCATE THE HOLE WHEN INSERTING THE HEATING ELEMENT)

MAINTENANCE & SERVICE – COOLING

REFRIGERATION SYSTEM TROUBLESHOOTING

There are two refrigerant pressure ports installed in the return air section of the unit which could be used to dialogue the refrigeration system, vacuum and add refrigerant without removing the whole air conditioner module.

To access these two pressure ports, the air filter access panel must be removed.

The pressure ports extend out of the coil block-off panel for about 2 inch which enables people to measure the suction temperature and liquid temperature besides the suction pressure and liquid pressure. With these four measured numbers, suction superheat and sub-cooling could be calculated.



FIGURE 40 – Refrigeration Pressure Ports

AIR CONDITIONER MODULE REMOVAL

To fix refrigerant leak or replace refrigeration components (compressor, TXV, filter drier, etc.), the whole air conditioner module must be removed. Following the below procedure to remove the air conditioner module from the cabinet for service if required. Electrical power to refrigeration chassis MUST be turned off.

 Remove screws(8) from top front panel, control cover panel and air filter access panel, then remove all these three panel from the cabinet. See FIGURE 41

 Removal of Front Panels.

DON'T REMOVE THE BOTTOM TWO SCREWS ON THE AIR FILTER ACCESS PANEL.



FIGURE 41 – Removal of Front Panels

FIRST-PAK - IOM

- 2) Remove power cable from unit.
- Disconnect low voltage (6 pin) & line voltage (3 pin) harness connectors by pressing on the release tabs and using a downward motion (FIGURE 43 - Line Voltage Connector (3 Pin) & FIGURE 44 - Low Voltage Connector (6 Pin).



FIGURE 42 – Electrical Power Disconnection

4) Remove gaskets before removing chassis.



FIGURE 47— Gasket Removal





FIGURE 44 - Low Voltage Connector (6 Pin)

5) Slide-out air conditioner module as shown in *Conditioner Module*



FIGURE 45 – Slide Out Air Conditioner Module

6) Side panel can be removed from the evaporator section to service the TXV.





MAINTENANCE & SERVICE – COOLING CONTINUED

AIR CONDITIONER MODULE REASSEMBLY

- 1) To put-back the chassis, make sure all the refrigerant lines are in place and there are no leaks.
- 2) Slide chassis back into the unit.
- 3) Connect the electrical connection back as they previously were.

PREVENTIVE MAINTENANCE

To achieve maximum performance and service life of equipment, a formal schedule of regular maintenance should be established and followed.



WARNING

It is illegal to discharge refrigerant into the atmosphere. Use proper reclaiming methods and equipment when installing or servicing this unit. Service should be performed by a QUALIFIED service agency. The refrigerant system contained in the unit normally requires no maintenance since it is a closed, self-contained system.

CAUTION

All appropriate personal protection equipment should be worn when servicing or maintaining this unit.

Personal injury can result from sharp metal edges, moving parts, and hot or cold surfaces.

FAN

For any other refrigeration servicing, the refrigeration chassis can be removed as explained in REMOVAL OF AC Section

FILTER

The air filter should be cleaned or replaced every 30 days or more frequently if severe operating conditions exist. Always replace the filter with the same type and size as originally furnished.

COIL

Clean all heat transfer surfaces and remove all dirt, dust, and contaminates that potentially impairs air flow using industry accepted practices. Care should be taken not to bend coil fin material.

CONDENSATE DRAIN PAN AND PIPE

Check and clean all dirt and debris from pan. Ensure drain line is free flowing and unobstructed.

UNIT PERFORMANCE

Record performance measurements of volts, amps, and air temperature differences. A comparison of logged data with

start-up and other annual data is useful as an indicator of general equipment condition.

Image: WarningImage: Warning<tr

Check motor connections to ensure they are secure and in accordance with the unit wiring diagram.

ECM motors have line voltage power applied at all times. MAKE SURE POWER IS DISCONNECTED BEFORE SERVICING.

CUSTOMER STARTUP DATE JOB

ADDRESS

FIRST-PAK - IOM

SERVICING COMPANY

TECHNICIAN

MODEL #

SERIAL # PHONE #

INSTALLATION CHECK LIST

Inspect the unit for transit	damage and	report any	y damage on	the carrier's	freight bill.

Check model number to insure it matches the job requirements.

STARTUP & PERFORMANCE CHECKLIST

Install field accessories and unit adapter panels as required. Follow accessory and unit installation manuals.

Verify field wiring, including the wiring to any accessories.

Check all multi-tap transformers, to insure they are set to the proper incoming voltage.

Prior to energizing the unit, inspect all the electrical connections.

Power the unit. Bump the motor contractor to check rotation. Three phase motors are synchronized at the factory. If the blower fans are running backwards, de-energize power to the unit, then swap two of the three incoming electrical lines to obtain proper phasing. Re-check.

Perform all start up procedures outline in the installation manual shipped with the unit.

Fill in the Start Up Information as outlined below and on the following page.

Provide owner with information packet. Explain the thermostat and unit operation.

START UP INFORMATION SHEET

ELECTRICAL

Supply Voltage	L1-L2	L3-L4	Compressor Amps	
Running Voltage	L1-L2	L3-L4	Blower Amps	
Secondary Voltage			Condenser Fan Amps	
	C (black	د) to G (green) Volts*		
	C (black	<) to W (white) Volts*		*With thermostat calling.
TEMPERATURES				
Outdoor Air Temperature		DB	WB	
Return Air Temperature		DB	WB	
Cooling Supply Air Tempe	erature	DB	WB	
Heating Supply Air Tempo	erature	DB	WB	
REFRIGERATION				

Suction Pressure (Prior to Startup) Psig Liquid Pressure (Prior to Startup) Psiq

STARTUP & PERFORMANCE CHECKLIST CONTINUED

UNIT OPERATION

1	ELECTRIC HEATER AMPS		
2	INDOOR BLOWER AMPS		
3	TEMPERATURE RISE		
	Supply Duct Temperature		
	Return Duct Temperature	-	
	Temperature Rise	=	
4	TOTAL EXTERNAL STATIC		
	Supply Duct Temperature		
	Return Duct Temperature	+	
	Temperature Rise	=	
COOLI	NG MODE		
5	INDOOR BLOWER AMPS		
6	TEMPERATURE DROP		
	Return Duct Temperature	·	
	Supply Duct Temperature	-	
	Temperature Drop	=	
7	TOTAL EXTERNAL STATIC (dry coil)		
	Supply External Static		
	Return External Static	+	
	Total External Static	=	
8	DRAIN LINE Leak Free		
9	THERMOSTAT Adjusted & Programmed Explained Operation to Owner		
10	REFRIGERATION		
	Suction Pressure	Psig	Liquid Pressure
	Suction Temperature	°F	Liquid Temperature

The warranty may be void unless the Startup & Performance Checklist is completed and returned to the warrantor. If the HVAC unit is not installed properly the warranty will be void as the manufacturer can't be held accountable for problems that stem from improper installation.

__Psig

_°F

INDEX OF FIGURES

	FIGURES	
FIGURE #	FIGURE DESCRIPTION	PAGE
1	Model Nomenclature	6
2	Standard Packaging	8
3	Standard Packaging with Shipping Brackets – Front View	9
4	Standard Packaging with Shipping Brackets – Back View	9
5	Unit Dimensions	10
6	Typical Floorplan with FIRST-PAK on Exterior Wall	13
7	Required Building Clearance	14
8	Interior Clearance Requirements	14
9	Wall Sleeve Mounting	15
10	Rear Installation Dimensions	15
11	Unit Support & Alignment	16
12	FIRST-PAK Unit Installation	17
13	Wall Sleeve Seal	18
14	Top Bracket Installation on Sleeve	18
15	Unit Return Ducting	19
16	Condensate Drain Layout	19
17	Air Filter Location	20
18	Cabinet with 5KW, 7KW, 10KW Heaters	21
19	Cabinet with 15KW Heater	21
20	Heater Electric Panel Layout	21
21	Thermostat Connections	22
22	Cooling Sequence of Operations	23
23	Blower Control Tap	24
24	Auto-Reset Temperature Limit Switch	27
25	Non-resettable Fuse Link	27
26	Slide Out Chassis Assembly	28
27	Electric Heater Assembly	28
28	Wiring Diagram	30
29	Wiring Diagram	31
30	Wiring Diagram	32
31	Wiring Diagram	33
32	Wiring Diagram	34
33	Wiring Diagram	35
34	Wiring Diagram	36
35	Wiring Diagram	36
36	Wiring Diagram	37
37	Wiring Diagram	<u>38</u>
38	Circuit Schematic	40
39	Front Top Panel Removal	44
40	Refrigeration Pressure Ports	45
41	Removal of Front Panels	45

INDEX OF FIGURES CONTINUED

FIGURES				
FIGURE #	FIGURE DESCRIPTION	PAGE		
42	Electrical Power Disconnection	46		
43	Line Voltage Connector (3 Pin)	46		
44	Low Voltage Connector (6 Pin)	46		
45	Slide Out Air Conditioner Module	46		
46	Side Panel Removal	46		
47	Gasket removal	46		

INDEX OF TABLES

TABLES				
TABLE #	TABLE DESCRIPTION	PAGE		
1	Physical Data	11		
2	Physical Data Continued	11		
3	Electrical Data	12		
4	Performance	12		
5	Clearance Requirements/ Dimensions	13		
6	Air Filter Minimum Dimensions	19		
7	Thermostat Connections Key	21		
8	Blower Performance Data	24		
9	Blower Performance Data Continued	25		
10	Replacement Parts	28		
11	Heating Troubleshooting Table	38		
12	Cooling Troubleshooting Table	3 9		

NOTES

Manufactured by:



8273 Moberly Lane Dallas, TX 75227 www.firstco.com

The manufacturer works to continually improve its products and as a result, it reserves the right to change design and specifications without notice.

©2022 First Co., 8273 Moberly Lane, Dallas, TX 75227